




TANKS  
AND  
OPTIONS

# GENERAL TANK CONFIGURATION



## TYPICAL OILFIELD STORAGE TANKING CONFIGURATION - ECONO VERSION

**ALWAYS SLOPE ALL LINES TO  
FLUID ACCUMULATOR DRUMS  
TO PREVENT FLUID TRAPS**



SPECIALIZED IN PREVENTING FUGITIVE EMISSIONS

Contact: 1 (956) 589 8832

[www.favsystems.com](http://www.favsystems.com)




TANKS  
AND  
OPTIONS

# GENERAL TANK CONFIGURATION



## MULTIPLE TANKS EQUIPPED WITH COMMON GAS BLANKETING HEADER

**ALWAYS SLOPE ALL LINES TO  
FLUID ACCUMULATOR DRUMS  
TO PREVENT FLUID TRAPS**



SPECIALIZED IN PREVENTING FUGITIVE EMISSIONS

Contact: 1 (956) 589 8832

[www.favsystems.com](http://www.favsystems.com)